



0-500 Power Tip Installation Instructions Fits Rhino 450 & 660 All Years

Hardware consists of:

- 1ea. 0-500 Power Tip
1. Remove product from packaging to insure all contents are included
 2. Remove three (3) stainless M6 fasteners from stock muffler
 3. Remove spark arrestor (round screen) from stock muffler tip (optional)
 4. Insert spark arrestor into muffler aligning holes in spark arrestor with threaded holes in muffler
 5. Place power tip flange against spark arrestor flange with power tip elbow pointing toward the ground (**away from any objects affected by heat**), aligning holes in flanges
 6. Re-insert stock M6 fasteners
 7. Tighten all three fasteners
 8. Hit the trails

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.