



0-520 Power Tip Installation Instructions Fits Rhino 700 08'

Hardware consists of:

- 1ea. 0-520 Power Tip
1. Remove product from packaging to insure all contents are included
 2. Remove three (3) stainless M6 fasteners from stock muffler
 3. Place power tip flange against muffler with power tip elbow pointing toward the ground (**away from any objects affected by heat**), aligning holes in flanges
 4. Re-insert stock M6 fasteners
 5. Tighten all three fasteners
 6. Hit the trails

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.