



## **Rhino Rear CV Guard Installation Instructions**

### **1-020**

Remove product from packaging.

Hardware consists of:

- 4ea. 1/4-20 x 3/4" BHCS SS
  - 4ea. 1/4-20 NYLOCK NUT
1. Jack rear of vehicle to release any tension from stabilizer bar.
  2. Remove stabilizer from a-arm using a 14 & 17 mm wrenches .
  3. Place guard in position.
  4. Re-attach the stabilizer bar through guard and a-arm.
  5. Insert 1/4" bolts into two rear holes passing through a-arm.
  6. Thumb the lock nut on each bolt.
  7. Tighten both stabilizer bar and rear bolts.
  8. Enjoy!!!!

If you have any questions, please call 423-569-3478 or visit [www.dirtperformance.net](http://www.dirtperformance.net) , e-mail question to [producttech@dirtperformance.net](mailto:producttech@dirtperformance.net).