



Dirt Performance, Inc.

Rhino Front CV Guard Installation Instructions

1-021

Remove product from packaging.

Hardware consists of :

- 4ea. 1/4-20 X 3/4 BHCS SS
- 4ea. 1/4-20 x 5/8 BHCS SS
- 4ea. 1/4-20 NYLOCK NUTS
- 4ea. 1-023 J-CLAMP

1. Remove O.E.M. boot guards.
2. Place new guard in position with largest side toward the front.
3. Insert 1/4-20 x 3/4" bolts into two bottom holes from underneath passing through a-arm.
4. Thumb the lock nut on each bolt.
5. Place aluminum j-clamp over the front a-arm tube aligning with holes in front side of guard.
6. Thread 1/4-20 x 5/8" bolts into j-clamp.
7. Tighten all bolts.
8. A third hole is provided in bottom of guard for an additional fastener if desired.
9. Enjoy!!!!

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.