



Dirt Performance, Inc.

Rhino Stick-Stopper Installation Instructions 1-022

Remove product from packaging.

Hardware consists of:

- 10ea. 1/4-20 x 3/4" BHCS SS
- 10ea. 1/4-20 NYLOCK NUTS
- 20ea. FLAT WASHER
- 6ea. 3/16 X 3/8L PIN DRIVE RIVET

1. Remove three (3) bolts and clip nuts from top of floor board on each side.
2. Remove plastic coating off of exterior of part
3. Place stick-stopper against outside of floorboard, fastening with 3/4" long bolts along top edge.(place one washer between bolt head and floorboard and one between stick-stopper and lock nut)
4. Using 9/32" drill bit, drill through the plastic O.E.M. floorboard, using holes provided in the stick-stoppers.
5. Repeat **step 4** for the inner hole at top of stick-stopper on the passenger side.
6. Insert two (2) 3/4" long bolts per side through floorboard and stick-stopper using one washer between head of bolt and floor pan.
7. Apply lock nut provided and washer.
8. Tighten all fasteners firmly.
9. Along the rear edge of the stick-stopper, (using the three (3) holes provided) drill a 3/16" hole into the round steel cross bar. Insert rivets into the hole, and hammer the center pin of the rivet flush with the head to tighten rivet.
10. Enjoy!!!!

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net.
E-mail question to producttech@dirtperformance.net.