



Rhino Seat / Engine Compartment Apron Installation Instructions 1-055D

Remove product from packaging.

Hardware consists of:

- **4 – ¼”-20 X 1 ¾” BHCS SS**
- **4 – ¼”-20 NYLOCK NUTS**
- **14 – 3/16” POP RIVET; 3/16 X 3/8 L**

1. Remove seats.
2. Remove (3) plastic phillip head fasteners from the side of the factory seat apron.
3. Place the center cover onto the existing plastic, position evenly so that ¾” flanges are flush or behind front of seat apron on each side.
4. Using 3/16” drill bit, transfer holes provided into the original plastic.
5. Fasten with pop-rivets provided.
6. Place the seat apron for each side over the existing seat apron.
7. Install (2ea. ¼-20 x 1 ¾” long button head bolts) into each of the (2) top holes. Using a lock nut to secure apron.
8. Position the part for proper fit and tighten all bolts.
9. Using 3/16” drill bit, drill through provided holes (careful not to puncture gas tank on passenger side) and insert rivets provided.
10. Replace seats.

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.