



Rhino Bright Aluminum Tread Floor Pan 1-056

Remove product from packaging.

Hardware consists of:

- **8 Ea 3/16 x 1/2 SMHD POP RIVET**
 - **4 Ea M5-0.8 X 25 HEX CAP SCREW Z**
 - **4 Ea #10 SAE FLAT WASHER Z**
1. Remove (4) screws from transmission hump.(Tunnel)
 2. Insert aluminum floor pan underneath hump and front of engine compartment.
 3. Replace original screws removed in step #1 with longer screws provided.
 4. Using 3/16" drill bit, drill through 4 small holes into frame.
 5. Install 3/16" pop rivets into the holes drilled in step #4.
 6. Installation is now complete.

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.