



Rhino Windshield Guard Installation Instructions

Hardware consists of:

- 2ea. WINDSHIELD GUARDS
 - 8ea. POP RIVETS; 3/16 X 3/8 L
1. Loosen up the 2 front roll cage bolts.
 2. Insert the windshield guard with 4 holes on the drivers side with the ears down, insert the ears into the bolts you loosened up on the roll cage and snug the bolts.
 3. Drill the holes on the top of guard into the roll cage using the 3/16 drill bit.
 4. Drive in the hammer rivets through the roll bar and bracket holes.
 5. Repeat steps 1-4 for other side.
 6. The other side is optional on 2 of the hammer rivets you can drill 2 extra holes if you want.
 7. Tighten firm all 4 bolts on roll bars bar.
 8. Enjoy!!!!

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.