



Dirt Performance, Inc.

Rhino 700 Rear CV Guard Installation Instructions

1-120

Remove product from packaging.
(Use factory hardware)

1. Remove factory guards. Be sure to keep bolts these will need to be reused to mount new guard.
2. Place guard in position.
3. Re-install the factory hardware.
4. Tighten all bolts
5. Enjoy!!!!

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.