



Rhino Sport Cage Installation Instructions 1-2000

1 cage

Hardware consists of:

- 8ea. 3/8"-16 x 1 1/4 HCS Z
- 8ea. NYLOCK WASHERS
- 2 PLATES

1. Remove bolts from rear top bar. Remove bar. **These bolts will be needed for assembly.**
Optional-You may want to install the rear bar in place of the front bar in order to maintain the grab handle.
2. Set the cage in place. Line up holes at the top (where the bar was removed). Align and loosely tighten bolts (use bolts that you took out of the bar). Do this for both sides.
3. Remove the mat from the bed. Find the holes located on the bed floor at the rear behind the fender wells.
4. Using a 3/8" drill bit, transfer the holes through the bed floor.
5. Slide plates that are provided (nuts facing down) underneath the bed inside channel and line up holes. Do this for both sides.
6. Install bolt (provided) and washer (provided) from top side. Thread into plate. Tighten loosely.
7. Once all bolts are aligned, tighten all bolts.
8. You may now want to replace the mat, cutting out for the roll cage bars.
9. Enjoy!!!!

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net, e-mail question to producttech@dirtperformance.net.