



Rhino Front Bed Liner

Installation Instructions

1-403

Remove product from packaging.
Hardware consists of:

- **5 – 3/16” POP RIVET; 3/16 X 3/8 L**
 1. Position the liner against the front of the bed.
 2. While holding firmly in place, drill 3/16” hole through the bed using provided holes for a guide.
 3. Insert a pop rivet into the first hole to ensure alignment while drilling remaining holes.
 4. Repeat steps 2-3 until all holes are drilled.
 5. Permanently fasten all rivets using a pop rivet gun.
 6. The installation is now complete.

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net , e-mail question to producttech@dirtperformance.net.