



## 1-405 Rhino Bed Liner Kit Installation Instructions

Remove all products from packaging.

Hardware consists of:

- 15ea. – 10-16 X 1/2 H/L TFS SS
- 9ea. –POP RIVETS; 3/16 X 3/8 L

1. Remove all D-Ring (tie strap hoops) brackets from the inside of the bed.
2. Remove the tailgate retaining cable from the bed side and the tailgate.
3. Find something stable enough to support the tailgate during installation.
4. Let tailgate down to the horizontal position.

### Rhino Front Bed Liner

5. **BE SURE TO INSTALL THIS PIECE FIRST FOR AN EASIER INSTALL.**
6. Position the liner against the front of the bed.
7. While holding firmly in place, drill 3/16" hole through the bed using provided holes for a guide.
8. Insert a pop rivet into the first hole to ensure alignment while drilling remaining holes.
9. Repeat steps 2-3 until all holes are drilled.
10. Permanently fasten all rivets using a pop rivet gun.

### Rhino Inner Bed Side Liner

11. Position the liner against the corresponding side of the bed.
12. Align the holes in the liner with the holes in the bed.
13. Replace D-Rings and fasteners. **(Do not tighten fasteners yet.)**
14. Drill 3/16" hole through the bed, using provided holes above wheel well for a guide. **(CAREFUL NOT TO DRILL THROUGH OUTER BED SIDE)**
15. Replace the tailgate cable and fastener into the bed side only. **(Do not tighten fasteners yet.)**
16. Align all edges to your satisfaction.
17. Tighten all fasteners.

### Rhino Tailgate Liner

18. Remove original liner using #2 combination screw driver.
19. Install 1-402 liner and insert stainless screws provided (optional).
20. Tighten all screws firmly.
21. Replace the cable retaining bolts.
22. The installation is now complete.