



Dirt Performance, Inc.

**RZR Rear Boot Guard
Installation Instructions
2-020**

Remove product from packaging.

Hardware consists of:

- **1ea. Left hand boot guard**
- **1ea. Right hand boot guard**
- **8ea. M8-1.25 X 45 UHWH**
- **8ea. M8-1.25 NYLOCK NUT**

1. Jack rear end of RZR up and place on jack stands.
2. Remove wheels and tires for easier access.
3. Remove the original plastic guards from each side.
4. Place the boot guard on the a-arm.
5. Start the M8 fastener (provided) through the guard and lower control arm. Thread a lock nut onto fastener finger tight.
6. Repeat **Step 5** for remaining fasteners and brackets. **Note: One extra hole is provided in boot guard. However, removal of the shock would be necessary for access to the nut. The hole is there if needed.**
7. The brake-line should rest on the hem provided. Make sure that the brake-line is not pinched or bound.
8. Tighten all fasteners.
9. Installation is now complete.

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net.

E-mail question to producttech@dirtperformance.net.