



**Dirt Performance, Inc.**  
**P/N 2-092 RZR Front Differential Skid**  
**Installation Instructions**

Remove product from packaging.

Hardware consists of:

- 1ea. Differential Skid
- 3ea. 1/4-20 X 1 UHWH TRS
- 3ea. 1/4-20 NYLOCK NUT
- 3ea. 1/4 FLAT WASHER

**Note:** If you're DPI Belly Skid (P/N 2-080) has previously been installed, the front fasteners will need to be loosened to allow the front diff. skid to slide between the belly skid and the frame.

1. Jack front end of RZR up and place on jack stands.
2. Place diff. skid against bottom of frame.
3. Insert **1/4-20 X 1 UHWH TRS** fasteners through the skid and the frame.
4. Apply flat washer and nut to each of the fasteners.
5. Tighten all fasteners.
6. Installation is now complete.

If you have any questions, please call 423-569-3478 or visit [www.dirtperformance.net](http://www.dirtperformance.net).

E-mail question to [producttech@dirtperformance.net](mailto:producttech@dirtperformance.net).