



1-028 Rhino Rear Differential Cover Installation Instructions

Remove all products from packaging.

Hardware consists of:

- 2 - ea. 1/4-14 X 3/4 HWHSD
- 1 – ea 1-028 Rear Differential Cover

1. Jack the rear end of the rhino up so the rear tires are off the ground.
2. Remove the passenger side top a-arm bolt. Turn the bolt around so the bolt threads are facing the back of the rhino. (DO NOT REINSTALL THE NUTS AT THIS TIME)
3. Repeat step two for the lower a-arm on the passenger side and for both a-arms on the driver's side.
4. Slide the differential cover over the threaded part of the bolts. Replace the nuts and tighten all four bolts.
5. Install 2 self drilling screws (One on each side of the differential plate) through the holes provided in the differential cover.

Note: The reason for reversing the a-arm bolts.

1. *To allow access to rear differential without having to totally remove the a-arm bolts.*

If you have any questions, please call 423-569-3478 or visit www.dirtperformance.net ,
E-mail question to producttech@dirtperformance.net.